



PLEASE READ THIS PAGE CAREFULLY BEFORE SELECTING EDIBLE INK TANKS AND PRINTERS

BASICALLY WE OFFER EDIBLE INK TANKS FOR MANY CANON AND EPSON PRINTERS, BUT YOU WILL ALSO FIND THAT MANY MODELS OF THESE PRINTERS HAVE NOW BEEN DISCONTINUED BY THE MANUFACTURER, BUT WE STILL HAVE TANK SETS THAT ARE SHOWN ON THESE PAGES

WE DO NOT HAVE EDIBLE INK TANKS FOR ALL PRINTERS, SO IF YOUR PRINTER IS NOT LISTED THEN WE JUST DO NOT HAVE THE TANKS.

WE OFTEN GET REQUESTS FOR EDIBLE INK TANKS FOR OTHER PRINTER BRANDS, SUCH AS H.P., LEXMARK, BROTHER, ETC., SO READ ON.....

WE DO OFFER EDIBLE INK REFILL KITS, WHICH CAN BE USED TO REFILL THESE MODELS, AS WELL AS ALL OTHER CANON OR EPSON MODELS THAT YOU DO NOT SEE LISTED ON OUR CROSS-REFERENCE LISTINGS (**LOOK FOR THE SHEET THAT IS CLOSEST FOR YOUR COUNTRY OR AREA**)

IF YOU CANNOT LOCATE A PRINTER IN YOUR LOCAL STORE, YOU CAN USUALLY PURCHASE PRINTERS DIRECTLY THROUGH THE PRINTER WEBSITES, SUCH AS... WWW.EPSON.COM or WWW.CANON.COM

\* THE LEAST EXPENSIVE PRINTERS ARE ALL THAT IS NEEDED TO DO YOUR EDIBLE PRINTING.

WHEN RE-ORDERING INDIVIDUAL TANKS, PLEASE USE OUR TANK NUMBERS FOUND ON THE FIRST SET OF YOUR KOPYKAKE EDIBLE INK TANK SET OR CALL FOR INFORMATION.

We do not have the tanks with Microchips for many models, but many customers have chosen to purchase our Re-Fill edible inks and refill their original Canon Tanks with our edible ink, or remove the Original Microchips that came with your printer, and insert them onto our edible ink tank sets, (such as our C225 series [USA] or C525 series [EURO] sets.

If you have any specific questions about tanks or printers, you may call us or email us. Best time is Monday - Friday 8:00am - 4:00pm Pacific Coast Time Please ask for Rudy at Extension 31.

IN USA: TOLLFREE 800-999-5253 / OUTSIDE OF USA 310-373-8906

# KOPYKAKE

## USA - CANADA - AND DOMESTIC CHART

# 1

CROSS REFERENCE CHART FOR OUR EDIBLE INK TANKS AND **CANON** AND **EPSON** PRINTERS

### USE THIS PAGE ONLY FOR PRINTERS PURCHASED IN U.S.A. OR CANADA

CANON	KOPYKAKE			EPSON	KOPYKAKE			P = PRINTER
MODEL #'S	TANK SET #			MODEL #'S	TANK SET #			A = ALL-IN-ONE
IP3600	C225SET-5	P		1400	T0797SET-6	P	X	
IP4600	C225SET-5	P		C88 or C88+	ESET605	P		
IP4700	C225SET-5	P		NX125	T1255SET-4		A	
IP4820	C235SET-5	P		NX127	T1255SET-4		A	
IP4920	C235SET-5	P		NX625	T1255SET-4		A	
IX6520	C235SET-5	P	X	Workforce 320	T1255SET-4		A	
MG5120	C235SET-5		A	Workforce 323	T1255SET-4		A	
MG5220	C235SET-5		A	Workforce 325	T1255SET-4		A	
MG5320	C235SET-5		A	Workforce 520	T1255SET-5		A	
MP540	C225SET-5		A	Workforce1100	T0695SET-5	P		
MP560	C225SET-5		A					X
MP620	C225SET-5		A					
MP640	C225SET-5		A					
MP860	C225SET-5		A					
MX860	C225SET-5		A					
MX870	C225SET-5		A					
MX882	C235SET-5		A					

#### OLDER MODEL CANONS

I560	6000SET-4	P	
I6500	6000SET-4	P	
IP3000	6000SET-4	P	
IP3300	CP42SET-4	P	
IP3500	CP42SET-4	P	
IP4000	6000SET-5	P	
IP4200	CP42SET-5	P	
IP4300	CP42SET-5	P	
IP4500	CP42SET-5	P	
IP5000	6000SET-5	P	
IP5200	CP42SET-5	P	
IP6000D	6000SET-6	P	
IP6600D	CP42SET-6	P	
IP6700D	CP42SET-6	P	
MP500	CP42SET-5		A
MP510	CP42SET-4		A
MP520	CP42SET-4		A
MP530	CP42SET-5		A
MP600R	CP42SET-5		A
MP610	CP42SET-5		A
MP750	6000SET-5		A
MP760	6000SET-5		A
MP780	6000SET-5		A
MP800	CP42SET-5		A
MP810	CP42SET-5		A
MP830	CP42SET-5		A
MX700	CP42SET-4		A

#### OLDER MODEL EPSONS

C87 or C87+	ESET605	P	
CX4200	ESET605		A
CX5000	T0695SET-4		A
CX6000	T0695SET-4		A
CX7000	T0695SET-4		A
CX7400	T0695SET-4		A
CX7800	ESET605		A
CX8400	T0695SET-4		A
CX9400	T0695SET-4		A
NX105	T0695SET-4		A
NX110	T0695SET-4		A
NX115	T0695SET-4		A
NX200	T0695SET-4		A
NX215	T0695SET-4		A
NX300	T0695SET-4		A
NX305	T0695SET-4		A
NX400	T0695SET-4		A
NX410	T0695SET-4		A
NX415	T0695SET-4		A
NX510	T0695SET-4		A
NX515	T0695SET-4		A
Workforce 30	T0695SET-5	P	
Workforce 40	T0695SET-4	P	
Workforce 310	T0695SET-5		A
Workforce 315	T0695SET-5		A
Workforce 500	T0695SET-4		A
Workforce 600	T0695SET-4		A
Workforce 610	T0695SET-4		A
Workforce 615	T0695SET-4		A

MODELS IN **BLACK** ARE OLDER PRINTERS - BUT ALL WORK WELL

ITEMS IN **RED** ARE THE MOST CURRENT MODELS

\* WE SUGGEST USING A COMPUTER WITH ALL PRINTERS FOR BEST RESULTS

PRINTERS WITH X PRINTS 11x17 (A3)

# KOPYKAKE

EURO EXPORT (NOT CHINA OR JAPAN)

USE THIS PAGE ONLY FOR PRINTERS  
PURCHASED IN EUROPE OR MIDDLE EAST

2

CROSS REFERENCE CHART FOR OUR EDIBLE INK TANKS AND **CANON** AND **EPSON** PRINTERS

CANON MODEL #S	PRINTERS TANK SET #		
IP3600	C525SET-5E	P	
IP4600	C525SET-5E	P	
IP4700	C525SET-5E	P	
IP4840	C425SET-5E	P	
IP4850	C535SET-5E	P	
IP4940	C425SET-5E	P	
IP4950	C535SET-5E	P	X
IX4000	CP42SET-4E	P	X
IX5000	CP42SET-4E	P	X
IX6540	C425SET-5E	P	
IX6550	C535SET-5E	P	
MG5140	C425SET-5E		A
MG5150	C535SET-5E		A
MG5240	C425SET-5E		A
MG5250	C535SET-5E		A
MG5340	C425SET-5E		A
MG5350	C535SET-5E		A
MG6250	C535SET-5E		A
MG8250	C535SET-5E		A
MP540	C525SET-5E		A
MP550	C525SET-5E		A
MP560	C525SET-5E		A
MP620	C525SET-5E		A
MP630	C525SET-5E		A
MP640	C525SET-5E		A
MX884	C425SET-5E		A
MX885	C535SET-5E		A

OLDER MODEL CANONS			
I560	6000SET-4E	P	
I6500	6000SET-4E	P	
IP3000	6000SET-4E	P	
IP3300	CP42SET-4E	P	
IP3500	CP42SET-4E	P	
IP4000	6000SET-5E	P	
IP4200	CP42SET-5E	P	
IP4300	CP42SET-5E	P	
IP4500	CP42SET-5E	P	
IP5000	6000SET-5E	P	
IP5200	CP42SET-5E	P	
IP5300	CP42SET-4E	P	
IP6000D	6000SET-6E	P	
IP6600D	CP42SET-6E	P	
IP6700D	CP42SET-6E	P	

EPSON MODEL #S	PRINTERS TANK SET #		
1400	T0697SET6E	P	X
B-42	T1295SET4E	P	
BX305	T1295SET4E		A
BX320	T1295SET5E		A
BX525	T1295SET4E		A
BX625	T1295SET4E		A
SX420	T1295SET4E		A
SX425	T1295SET4E		A
SX525	T1295SET4E		A
SX620	T1295SET4E		A

MODELS IN **BLACK** ARE OLDER PRINTERS - BUT ALL WORK WELL

ITEMS IN **RED** ARE THE MOST CURRENT MODELS

\* WE SUGGEST USING A COMPUTER WITH ALL PRINTERS FOR BEST RESULTS

OLDER MODEL CANONS			
MP500	CP42SET-5E		A
MP510	CP42SET-4E		A
MP520	CP42SET-4E		A
MP530	CP42SET-5E		A
MP600	CP42SET-5E		A
MP610	CP42SET-5E		A
MP750	6000SET-5E		A
MP760	6000SET-5E		A
MP780	6000SET-5E		A
MP800	CP42SET-5E		A
MP810	CP42SET-5E		A
MP830	CP42SET-5E		A
MX700	CP42SET-4E		A

PRINTERS WITH X PRINTS 11x17 (A3)

P = PRINTER ONLY

A = ALL-IN-ONE

EPSON MODEL #S	PRINTERS TANK SET #		
C87 or C87+	ESET605E	P	
C110	T0735SET5E	P	
D120	T0715SET5E	P	
D88 or D88+	ESET605E	P	
DX4000	T0715SET4E		A
DX4400	T0715SET4E		A
DX4450	T0715SET4E		A
DX5050	T0715SET4E		A
DX6000	T0715SET4E		A
DX7000	T0715SET4E		A
DX7400	T0715SET4E		A
DX7450	T0715SET4E		A
DX8400	T0715SET4E		A
DX8450	T0715SET4E		A
S20	T0715SET4E	P	
SX100	T0715SET4E		A
SX105	T0715SET4E		A
SX115	T0715SET4E		A
SX200	T0715SET4E		A
SX205	T0715SET4E		A
SX210	T0715SET4E		A
SX215	T0715SET4E		A
SX218	T0715SET4E		A
SX400	T0715SET4E		A
SX400	T0715SET4E		A
SX405	T0715SET4E		A
SX410	T0715SET4E		A
SX510	T0715SET4E		A
SX515	T0715SET4E		A
SX600	T0715SET4E		A
SX610	T0715SET4E		A
T20	T0735SET4E	P	
T21	T0735SET4E	P	
T30	T0735SET5E	P	
TX100	T0735SET4E		A
TX110	T0735SET4E		A
TX200	T0735SET4E		A
TX400	T0735SET4E		A
TX410	T0735SET4E		A
TX550	T0735SET4E		A

# KOPYKAKE

AUSTRALIA - NEW ZEALAND

**USE THIS PAGE ONLY FOR PRINTERS  
PURCHASED IN AUSTRALIA AND NEW ZEALAND**

# 3

CROSS REFERENCE CHART FOR OUR EDIBLE INK TANKS AND **CANON** AND **EPSON** PRINTERS

<b>CANON</b>	<b>PRINTERS</b>		
<b>MODEL #S</b>	<b>TANK SET #</b>		
IP3600	C525SET-5E	P	
IP4600	C525SET-5E	P	
IP4700	C525SET-5E	P	
IP4850	C535SET-5E	P	
IP4950	C535SET-5E	P	
IX4000	CP42SET-4E	P	X
IX5000	CP42SET-4E	P	X
IX6550	C535SET-5E	P	X
MG5150	C535SET-5E		A
MG5250	C535SET-5E		A
MG5350	C535SET-5E		A
MP540	C525SET-5E		A
MP550	C525SET-5E		A
MP560	C525SET-5E		A
MP620	C525SET-5E		A
MP630	C525SET-5E		A
MP640	C525SET-5E		A
MX8250	C525SET-5E		A
MX870	C525SET-5E		A
MX885	C525SET-5E		A

**OLDER MODEL CANONS**

I560	6000SET-4E	P	
I6500	6000SET-4E	P	
IP3000	6000SET-4E	P	
IP3300	CP42SET-4E	P	
IP3500	CP42SET-4E	P	
IP4000	6000SET-5E	P	
IP4200	CP42SET-5E	P	
IP4300	CP42SET-5E	P	
IP4500	CP42SET-5E	P	
IP5000	6000SET-5E	P	
IP5200	CP42SET-5E	P	
IP5300	CP42SET-4E	P	
IP6000D	6000SET-6E	P	
IP6600D	CP42SET-6E	P	
IP6700D	CP42SET-6E	P	
MP500	CP42SET-5E		A
MP510	CP42SET-4E		A
MP520	CP42SET-4E		A
MP530	CP42SET-5E		A
MP600	CP42SET-5E		A
MP610	CP42SET-5E		A
MP750	6000SET-5E		A
MP760	6000SET-5E		A
MP780	6000SET-5E		A
MP800	CP42SET-5E		A
MP810	CP42SET-5E		A
MP830	CP42SET-5E		A
MX700	CP42SET-4E		A

<b>EPSON</b>	<b>PRINTERS</b>				<b>P = PRINTER</b>
<b>MODEL #S</b>	<b>TANK SET #</b>				<b>A = ALL-IN-ONE</b>
1410	T0817SET6E	P			X
ARTISAN 725	T0817SET6E			A	
ARTISAN 835	T0817SET6E			A	
C110	73HNSET5-E	P			
N11	T1335SET4E	P			
NX125	T1335SET4E			A	
NX130	T1335SET4E			A	
T1100	73HNSET5E	P			
TX420	T1385SET4E			A	
Workforce 320	T1385SET4E			A	
Workforce 325	T1385SET4E			A	
Workforce 625	T1385SET4E			A	
Workforce 630	T1385SET4E			A	
Workforce 633	T1385SET4E			A	
Workforce 840	T1385SET4E			A	

**OLDER MODEL EPSONS**

C87 or C87+	ESET605E	P	
NX220	73HNSET4E		A
R290	T0817SET6E	P	
R390	T0817SET6E	P	
RX590	T0817SET6E		A
RX610	T0817SET6E		A
RX690	T0817SET6E		A
T20	T0735SET4E	P	
T21	T0735SET4E	P	
T30	73HNSET5E	P	
T40W	73HNSET4E	P	
T50	T0817SET6E	P	
TX100	T0735SET4E		A
TX110	T0735SET4E		A
TX200	73HNSET4E		A
TX210	73HNSET4E		A
TX300F	73HNSET4E		A
TX400	73HNSET4E		A
TX410	73HNSET4E		A
TX510FN	73HNSET4E		A
TX550W	73HNSET4E		A
TX600FW	73HNSET4E		A
TX610FW	73HNSET4E		A
TX650	T0817SET6E		A
TX700W	T0817SET6E		A
TX710	T0817SET6E		A
TX800FW	T0817SET6E		A
TX810FW	T0817SET6E		A

MODELS IN **BLACK** ARE OLDER PRINTERS - BUT ALL WORK WELL

ITEMS IN **RED** ARE THE MOST CURRENT MODELS

**\* WE SUGGEST USING A COMPUTER WITH ALL PRINTERS FOR BEST RESULTS**

**PRINTERS WITH X PRINTS 11x17 (A3)**

# KOPYKAKE

MEXICO AND SOUTH AMERICA

**USE THIS PAGE ONLY FOR PRINTERS  
PURCHASED IN MEXICO & SOUTH AMERICA**

4

CROSS REFERENCE CHART FOR OUR EDIBLE INK TANKS AND **CANON** AND **EPSON** PRINTERS

<b>CANON</b>	<b>PRINTERS</b>		
<b>MODEL #'S</b>	<b>TANK SET #</b>		

IP3600	C225SET-5	P	
IP4600	C225SET-5	P	
IP4700	C225SET-5	P	
IP5000	6000SET-5	P	X
IX4000	CP42SET-4	P	X
IX5000	CP42SET-4	P	
MG5210	C235SET-5		A
MP540	C225SET-5		A
MP550	C225SET-5		A
MP560	C225SET-5		A
MP620	C225SET-5		A
MP630	C225SET-5		A
MP640	C225SET-5		A

#### OLDER MODEL CANONS

I560	6000SET-4	P	
I6500	6000SET-4	P	
IP3000	6000SET-4	P	
IP3300	CP42SET-4	P	
IP3500	CP42SET-4	P	
IP4000	6000SET-5	P	
IP4200	CP42SET-5	P	
IP4300	CP42SET-5	P	
IP4500	CP42SET-5	P	
IP5200	CP42SET-5	P	
IP5300	CP42SET-4	P	
IP6000D	6000SET-6	P	
IP6600D	6000SET-6	P	
IP6700D	6000SET-6	P	
MP500	CP42SET-5		A
MP510	CP42SET-4		A
MP520	CP42SET-4		A
MP530	CP42SET-5		A
MP600	CP42SET-5		A
MP610	CP42SET-5		A
MP750	6000SET-5		A
MP760	6000SET-5		A
MP780	6000SET-5		
MP800	CP42SET-5		A
MP810	CP42SET-5		A
MP830	CP42SET-5		A
MX700	CP42SET-4		A

<b>EPSON</b>	<b>PRINTERS</b>			<b>P = PRINTER</b>
<b>MODEL #'S</b>	<b>TANK SET #</b>			<b>A = ALL-IN-ONE</b>

1410	T0817SET-6	P		X
T22	T1325SET-4	P		
T25	T1355SET-4	P		
TX120	T1325SET-4		A	
TX123	T1355SET-4		A	
TX125	T1355SET-4		A	
TX320	T1386SET-4		A	
TX420	T1386SET-4		A	

#### OLDER MODEL EPSONS

TX400	T0735SET-4		A	
TX410	T0735SET-4		A	
TX700W	T0817SET-6		A	
C87 or C87+	ESET605	P		
R290	T0817SET-6	P		
R390	T0817SET-6	P		
RX590	T0817SET-6		A	
RX610	T0817SET-6		A	
T50	T0817SET-6	P		
TX200	T0735SET-4		A	
TX210	T0735SET-4		A	
TX300F	T0735SET-4		A	

MODELS IN **BLACK** ARE OLDER PRINTERS - BUT ALL WORK WELL

ITEMS IN **RED** ARE THE MOST CURRENT MODELS

\* WE SUGGEST USING A COMPUTER WITH ALL PRINTERS FOR BEST RESULTS

**PRINTERS WITH X PRINTS 11x17 (A3)**

# KOPYKAKE

## PHILIPPINES

**USE THIS PAGE ONLY FOR PRINTERS**

**PURCHASED IN PHILIPPINES, ASIA, MALAYSIA**

# 5

CROSS REFERENCE CHART FOR OUR EDIBLE INK TANKS AND **CANON** AND **EPSON** PRINTERS

CANON MODEL #'S	PRINTERS TANK SET #
--------------------	------------------------

CANON MODEL #'S	PRINTERS TANK SET #
--------------------	------------------------

EPSON MODEL #'S	PRINTERS TANK SET #
--------------------	------------------------

IP3600	C525SET-5E	P	
IP3680	C825SET-5E	P	
IP4600	C525SET-5E	P	
IP4700	C525SET-5E	P	
IP4760	C825SET-5E	P	
IP4680	C825SET-5E	P	
IP4870	C725SET-5E	P	
IP4970	C725SET-5E	P	
IX4000	CP42SET-4E	P	X
IX5000	CP42SET-4E	P	X
IX6560	C725SET-5E	A	X
MG5170	C725SET-5E	A	
MG5270	C725SET-5E	A	
MG5370	C725SET-5E	A	
MP540	C525SET-5E	A	
MP550	C525SET-5E	A	
MP560	C525SET-5E	A	
MP620	C525SET-5E	A	
MP630	C525SET-5E	A	
MP640	C525SET-5E	A	

P = PRINTER
A = ALL-IN-ONE

T1100	73HNSET5E	P		X
T12	T1335SET4E	P		
T22	T1335SET4E	P		
TX120	T1335SET4E		A	
TX129	T1335SET4E		A	
TX320	T1335SET4E		A	
TX325	T1385SET4E		A	

ITEMS IN **RED** ARE THE MOST CURRENT MODELS

MODELS IN **BLACK** ARE OLDER PRINTERS - BUT ALL WORK WELL

PRINTERS WITH X PRINTS 11x17 (A3)

\* WE SUGGEST USING A COMPUTER WITH ALL PRINTERS FOR BEST RESULTS

### OLDER MODEL EPSONS

C87 or C87+	ESET605E	P	A
T30	T0735SET4E		A
T40W	T0735SET4E		A
TX100	T0735SET4E		A
TX110	T0735SET4E		A
TX210	T0735SET4E		A
TX300F	T0735SET4E		A
TX510FN	T0735SET4E		A
TX550W	T0735SET4E		A

### OLDER MODEL CANONS

I560	6000SET-4E	P	
I6500	6000SET-4E	P	
IP3000	6000SET-4E	P	
IP3300	CP42SET-4E	P	
IP3500	CP42SET-4E	P	
IP4000	6000SET-5E	P	
IP4200	CP42SET-5E	P	
IP4300	CP42SET-5E	P	
IP4500	CP42SET-5E	P	
IP5000	6000SET-5E	P	
IP5200	CP42SET-5E	P	
IP5300	CP42SET-4E	P	
IP6000D	6000SET-6E	P	
IP6600D	CP42SET-6E	P	
IP6700D	CP42SET-6E	P	
MP500	CP42SET-5E	A	
MP510	CP42SET-4E	A	
MP520	CP42SET-4E	A	
MP530	CP42SET-5E	A	
MP600	CP42SET-5E	A	
MP610	CP42SET-5E	A	
MP750	6000SET-5E	A	
MP760	6000SET-5E	A	
MP780	6000SET-5E	A	
MP800	CP42SET-5E	A	
MP810	CP42SET-5E	A	
MP830	CP42SET-5E	A	
MX700	CP42SET-4E	A	

# KOPYKAKE

## SOUTH AFRICA

**USE THIS PAGE ONLY FOR PRINTERS  
PURCHASED IN SOUTH AFRICA**

# 6

CROSS REFERENCE CHART FOR OUR EDIBLE INK TANKS AND **CANON** AND **EPSON** PRINTERS

CANON	PRINTERS		
MODEL #'S	TANK SET #		
IP3600	C525SET-5E	P	
IP4600	C525SET-5E	P	
IP4700	C525SET-5E	P	
IP4840	C425SET-5E	P	
IP4850	C535SET-5E	P	
IP4940	C425SET-5E	P	
IP4950	C535SET-5E	P	
IX4000	CP42SET-4E	P	X
IX5000	CP42SET-4E	P	X
IX6540	C425SET-5E	P	X
IX6550	C535SET-5E	P	X
MP540	C525SET-5E		A
MP550	C525SET-5E		A
MP560	C525SET-5E		A
MP620	C525SET-5E		A
MP630	C525SET-5E		A
MP640	C525SET-5E		A

### OLDER MODEL CANONS

I560	6000SET-4E	P	
I6500	6000SET-4E	P	
IP3000	6000SET-4E	P	
IP3300	CP42SET-4E	P	
IP3500	CP42SET-4E	P	
IP4000	6000SET-5E	P	
IP4200	CP42SET-5E	P	
IP4300	CP42SET-5E	P	
IP4500	CP42SET-5E	P	
IP5000	6000SET-5E	P	
IP5200	CP42SET-5E	P	
IP5300	CP42SET-4E	P	
IP6000D	6000SET-6E	P	
IP6600D	CP42SET-6E	P	
IP6700D	CP42SET-6E	P	
MP500	CP42SET-5E		A
MP510	CP42SET-4E		A
MP520	CP42SET-4E		A
MP530	CP42SET-5E		A
MP600	CP42SET-5E		A
MP610	CP42SET-5E		A
MP750	6000SET-5E		A
MP760	6000SET-5E		A
MP780	6000SET-5E		A
MP800	CP42SET-5E		A
MP810	CP42SET-5E		A
MP830	CP42SET-5E		A
MX700	CP42SET-4E		A

EPSON	PRINTERS	P = PRINTER A = ALL-IN-ONE		
MODEL #'S	TANK SET #			
1400	T0797SET6E	P		X
B42	T1295SET4E	P		
BX320	T1295SET4E		A	
BX610	T1295SET4E		A	
BX625	T1295SET4E		A	
SX420	T1295SET4E		A	
SX525	T1295SET4E		A	

### OLDER MODEL EPSONS

B40	T0715SET4E	P	
BX305	T0715SET4E		A
BX310	T0715SET4E		A
C110	T0735SET5E	P	
C87 or C87+	ESET605E	P	
SX218	T0715SET4E		A
SX415	T0715SET4E		A
SX510	T0715SET4E		A
SX515	T0715SET4E		A
SX610	T0715SET4E		A
T1100	T0735SET5E	P	
T209	T0735SET4E	P	
T219	T0735SET4E	P	
T30	T0735SET4E	P	
T40W	T0735SET4E	P	
TX200	T0735SET4E		A
TX210	T0735SET4E		A
TX300F	T0735SET4E		A
TX400	T0735SET4E		A
TX409	T0735SET4E		A
TX410	T0735SET4E		A
TX419	T0735SET4E		A
TX550W	T0735SET4E		A
TX600FW	T0735SET4E		A

MODELS IN **BLACK** ARE OLDER PRINTERS - BUT ALL WORK WELL

ITEMS IN **RED** ARE THE MOST CURRENT MODELS

\* WE SUGGEST USING A COMPUTER WITH ALL PRINTERS FOR BEST RESULTS

**PRINTERS WITH X PRINTS 11x17 (A3)**